

The attempt of using GaN (Cs) as a photocathode in SRF injector


J. Schaber^{1,2}, R. Xiang¹, J. Teichert¹, A. Arnold¹, P. Michel¹, P. Murcek¹

¹Helmholtz-Center Dresden-Rossendorf (HZDR), Dresden, Germany

² Technische Universität Dresden, Germany


1. Introduction

SRF Gun II



desireable requirements for photocathodes

- searching for better photocathodes is one of the principle challenge for photoinjectors
- average current up to several mA is desirable
- novel III-V semiconductor with direct & wide band gap (3.4 eV)





2. GaN (Cs)

GaN & its characteristics

- high QE (~40%)
- working wavelength range of 150 nm- 400 nm
- negative electron affinity (NEA) → only with Cs
- High robustness: resistant to vacuum contamination
- Good storage: ~3 years under nitrogen atmosphere

$$QE = \frac{N_{\text{generated electrons}}}{N_{\text{incident photons}}}$$



cesium activation & NEA

- Mg doping is necessary → increases diffusion length of e⁻ to surface
- activation with monolayer of Cs → work function near surface is lowered below vacuum level (NEA)

[S. Uchiyama., et al., APL 86, 103511 (2005)]

Table 1: Comparison of different photocathodes for SRF Guns

Property [Unit]	K ₂ CsSb	Cs ₂ Te	GaAs	Cu	Mg	GaN
harmonic *	2	4	2	4	4	3
λ [nm]	532	266	532	266	266	365
QE [%]	8	5	5	1.4E-2	0.5	~40
lifetime [hours]	4	> 100	~58	> 1 year	> 1 year	several years
response time [ps]	prompt	prompt	< 40	prompt	prompt	???
vacuum tolerance	poor	very good	poor	excellent	excellent	excellent

* For drive laser: Nd:YAG, output at 1064 nm

Introduction to the physics of electron emission, K.L.Jensen, 2017, p. 444 f.
Bazarov, Ivan V. et al. 2009. "Thermal Emission and Response Time Measurements of a GaN Photocathode." Journal of Applied Physics 105(8).

4. Ongoing working plan

analytical chemistry

- SEM, TEM & AFM
- XRD, XPS & EDX
- RBS & AES
- PL & QE

- cleaning process of GaN wafer? (analytic surface chemistry)
- compare GaN on different substrate material
- chemical stability under intensive laser?
- processing in SRF Gun II?


Modification of activation chamber

combination with SEM/EDX

- easy measurement of activated GaN
- detect contaminations/ lattice impurities

sample changement


- easy handling
- transfer from glove box without air exposure




activation chamber



cathode bodies for SRF Gun II




wafer holder design




GaN (9 mm x 9 mm)


measurements in SRF Gun II



3. First activation treatments



test chamber, vacuum 2x10⁻⁹mbar




GaN on sapphire


sample pre-treatment

- Ultrasonic bath in MeOH (3 min)
- etch in H₂SO₄: H₂O₂ (4:1) (5 min)
- rinse with H₂O and MeOH

- sample of 10⁻¹⁷-level p-doped GaN grown on sapphire substrate
- Pre-heat treatment to remove absorbed residual gases on GaN surface
- activated with Cs-dispenser (SAES) to achieve the NEG surface
- background vacuum in the test chamber dropped down during activation



710°C seems suitable for the heat cleaning of GaN. 5% is the best QE in the activation tests on the same sample



The process of the 4th cycle activation. 262 nm laser is used for the process detect. 500 V bias is added on the anode

Acknowledgement

We would like to thank all our colleagues in ELBE for their support in this work. We acknowledge the support of the German Federal Ministry of Education and Research grant 05K12CR1.

Contact:

M. Sc. Jana Schaber • Institute of Radiation Physics, Radiation Source ELBE • E-mail: j.schaber@hzdr.de • www.hzdr.de